

## IMPORTANT INFORMATION:

Always treat the "Inferno" (and any other firearm) as if it were loaded, this will avoid unpleasant "surprises". The "Inferno" paintball gun is not a toy, it can cause injury or death if misused. Always use a barrel plug when not playing. When using the "Inferno" you must make sure that yourself and anyone who is within range is wearing approved eye and ear protection.

Please make sure that this manual is included with the gun if you sell this paintgun. Read these instructions prior to use. Always make sure that both you and anyone within range are wearing approved eye protection. Always store the paintgun with the gas tank and loader removed.

If you need to make sure that the paintgun is un-loaded then do this by removing the loader and then tipping any remaining balls out of the breech and then firing the gun twice while pointed in a SAFE direction and then remove the gas source.

**WARNING** - Never look into the barrel while it is installed on the marker.  
If using compressed air as a propellant then only use the correct lubricants as recommended by the air system manufacturer. Whichever propellant gas you use make sure that only approved experts work on any part of the cylinder or air regulator. Remember, compressed gases can kill, they must be treated with respect.

**WARNING** -The "Inferno" may sometimes fire spontaneously if energised with a gas source without first cocking the hammer, so always wear safety goggles.

**WARNING** - Do not attempt to dismantled the Inferno beyond removing the barrel and bolt without first making sure that it is unloaded and de-gassed.




Powerball Limited, Unit 7, Elliott Industrial Park, Eastern Road, Aldershot, Hampshire, GU12 4TF  
Email: sales@powerball.co.uk Tel: 01252 408 550 Fax: 01252 408 551 www.powerball.co.uk

© 1997-2008 Arrow Precision, LLC. All rights reserved. Inferno and Terminator are trademarks of Arrow Precision Limited.

# INFERNO

Quality that speaks for itself

## Basic Maintenance Guide




Keep your marker working for longer  
and **increase your profits...**

Please keep for future reference

# The following is a quick guide to the basic maintenance of your marker.


Basic Maintenance should be carried out after each game, failure to do so will void your Manufactures Warranty. A full strip of the gun should be done when your marker is subjected to adverse conditions.

**WARNING - Do not attempt to dismantled the Inferno beyond removing the barrel and bolt without first making sure that it is unloaded and de-gassed.**




## Stage 1

Remove the cocking handle (part No. 0034) from the main body (Part No. 1310).



## Stage 2

Remove the main bolt from Inferno, (Part No. 0045) should slide out esaily.




## Stage 3

Squeegee the inferno with a Powerball Bow Tie Squeegee making sure it removes all dirt.



## Stage 4

Using Inferno lube squirt a few drops on the long bolt.



## Stage 5

Place long bolt back into the inferno marker. Make sure that the holes are facing up.



## Stage 6

Push the cocking handle back into the long bolt. The knurled part should be facing up. It should click into place.

**NO ALKALINE OR SOAP CLEANERS ARE TO BE USED AS THIS ATTACKS THE ALUMINIUM PARTS**

**WIPE CLEAN THE EXTERIOR WITH AN OILY RAG OR MOISTENED SPONGE. DO NOT IMMERSE MARKERS IN WATER!**

**These instructions to be used in conjunction with user manual**

**If you have any questions please call us on: 01252 408 550**

You must use a chronograph to measure the firing velocity of your gun. The velocity must not exceed 300 feet per second (the limit at some fields may be less).